

# USP <800> Surface Wipe Sampling Test

## Verify Workplace Safety in 4 Easy Steps

### 1 Buy Texwipe Swabs Part No TX714K

Texwipe swabs enhance absorbency, increase lifting, and capture small particles.

#### Potential swab vendors:

- Letco Medical
- Cole-Parmer
- Fisher Scientific
- Texwipe
- VWR

### 2 Identify Swab Areas

According to USP <800>, swab sampling should be performed routinely.

#### Sample Collection Areas:

- Inside of C-PEC
- Pass-through chambers
- Staging and work surfaces
- Floors and dispensing areas
- Outside HD buffer room or C-SCA
- Patient administration

### 3 Collect Sample

- Wet swab and shake off excess water
- Swab sampling area
- Place swab in vial
- Cut swab handle at perforation
- Cap Vial
- Label vial with sample collection area
- Change gloves and repeat process for other sampling areas

### 4 Submit Sample

Visit [www.arlok.com/HDs](http://www.arlok.com/HDs) for list of available drugs. Call ARL for drugs not listed.

#### Sample Shipment:

- Package vials for shipping and include cool packs
- Write USP <800> testing on sample submission form and list drugs to be tested
- Results delivered in 10 business days

**\$200 for 1<sup>st</sup> HD + \$50 for each additional HD per swab sample**

**CONTACT ARL TODAY**

**Email:** [info@arlok.com](mailto:info@arlok.com)

**Website:** [www.arlok.com](http://www.arlok.com)

**Toll Free:** (800) 393-1595